




# SCIENTIFIC INSTRUMENTS

## COMPONENT MAINTENANCE MANUAL B7040-2

Overall Length	5.05 in. (128.3 mm) maximum
Mounting Thread	3/4 – 16 UNF- 3A
Mounting Hexagon	1.00 in. (25.4 mm) across flats

\* This plug is listed for test purposes only, and is not necessarily used on the aircraft.



Outline and Schematic Drawing  
Figure 1

### TESTING AND FAULT ISOLATION

#### 4. TESTING AND FAULT ISOLATION

A. The data that follows permits the testing of the sensor to insure correct operation.

B. Special Tools and Test Equipment

- (1) A megohmmeter capable of reading 5 megohms and greater at 500 VDC (AEMC Model 1000, or equivalent)
- (2) Temperature-controlled environmental test chamber. Accuracy 1%.
- (3) Thermometer with temperature accuracy  $\pm 0.2^{\circ}\text{F}$  ( $\pm 0.11^{\circ}\text{C}$ )
- (4) Ohmmeter with:

Current: <math><0.1 \text{ mA}</math>

Accuracy: 0.05%

Range: 0-100  $\text{k}\Omega$

C. Visual Check


- (1) Visually check the sensor for obvious damage.

D. Insulation Resistance

- (1) Using the megohmmeter, measure the resistance between all receptacle pins and the housing. The reading should exceed 5 megohms @ 500 VDC.

E. Electrical Test (refer to Figure 2)

- (1) Connect the Ohmmeter to pins 1 & 2 of the temperature sensor. Hold the sensor at a temperature of  $37^{\circ}\text{F} \pm 2^{\circ}\text{F}$  ( $2.8^{\circ}\text{C} \pm 1.1^{\circ}\text{C}$ ), within the environmental test chamber. With the thermometer at a stable temperature and located within approximately 1/2 in. (12.7 mm) of the tip of the sensor, measure the temperature. Compare this value to that indicated on Figure 3. The value must be within the limits shown on the drawing.




Schematic for Electrical Test.  
Figure 2



COMPONENT MAINTENANCE MANUAL  
B7040-2

Resistance vs Temperature



Resistance vs Temperature  
Figure 3

5. DISASSEMBLY

Not Applicable

6. CLEANING

- A. Remove dirt, stains, moisture, etc. with a clean, dry, lint-free cloth.
- B. Use a soft bristle brush moistened in isopropyl alcohol to remove any foreign matter from between the receptacle pins.

7. CHECK

- A. Visually inspect the sensor probe for obvious wear or damage.
- B. Check for bent, broken or missing receptacle pins.



COMPONENT MAINTENANCE MANUAL  
B7040-2

C. Check probe housing for scratches or cracks.

8. REPAIR

The temperature sensor is considered non-repairable. Bent receptacle pins may be carefully straightened. For other defects or incorrect operation, the temperature sensor should be discarded.

9. ASSEMBLY INCLUDING STORAGE

A. Assembly

(1) Not Applicable

B. Storage

(1) Install a protective cap on the electrical connector.

(2) You must keep the sensor in a clean and dry room open to the air. The temperature must be between 18°C and 28°C (64°F and 82°F) and the relative humidity between 25% and 65%.

(3) Keep the sensor in its initial packaging. If you put other containers on the sensor container, be careful to prevent damage caused by too much weight.

(4) Do not keep the sensor near heat, fluids or other sources that can cause corrosion.

10. FITS AND CLEARANCES

No dimensional check of the sensor is necessary.

11. SPECIAL TOOLS, FIXTURES AND EQUIPMENT

No other special tools are necessary.

12. ILLUSTRATED PARTS LIST

Since the unit is non-repairable, no parts list is provided.