



TWINPAK MIXING INSTRUCTIONS

Burstable Twinpak

- 1) Carefully remove outer poly or foil bag without puncturing the inner Twinpak.
- 2) Roll up one end of the Twinpak sleeve and press down to burst seal between A and B.
- 3) Run the Twinpak sleeve back and forth from end to end over the edge of a bench approximately 40-50 times or 20-25 back and forth cycles.
- 4) If you see striations, non-uniform color, or if your resins do not have contrasting colors, mix an additional 10-15 cycles.
- 5) The Twinpak sleeve with mixed residue in most cases can be discarded as non-hazardous waste.

Note: Read MSDS prior to mixing or dispensing and use appropriate personal protective equipment i.e. safety glasses and rubber gloves.

